


Remote Administrator Guide



HP NetServer LC II Integrated Remote Assistant

Remote Administrator Guide
Guide de l'administrateur pour la
gestion à distance

Handbuch zur Fernverwaltung
Guía del Administrador Remoto
Guida per l'amministratore remoto



Configuration and Use

Configuration et utilisation

Konfiguration und Verwendung

Configuración y Uso

Configurazione e uso

HP NetServer LC II

Remote Administrator Guide

**Guide de l'administrateur
pour la gestion à distance**

Handbuch zur Fernverwaltung

Guía del Administrador Remoto

Guida per l'amministratore remoto



HP Part Number 5967-4522

Printed April 1998

BIBLIOTHEQUE DU CERIST

HP NetServer LC II Remote Administrator Guide

Configuring and Using Your
Integrated Remote Assistant



Notice

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

Materials reprinted with the permission of Symantec. Symantec makes no warranty of any kind regarding the accuracy, correctness, or sufficiency of the information in the publication, and the use of any information therein is or will be free from claims of intellectual property infringement of any kind.

Microsoft and MS-DOS are U.S. registered trademarks of Microsoft Corp. Windows and Windows NT are trademarks of Microsoft Corp. Novell and NetWare are registered trademarks of Novell, Inc. IBM and OS/2 are registered trademarks of the International Business Machines Corp. SCO, SCO UNIX, and Open Desktop are registered trademarks of The Santa Cruz Operation. SCO Open Server and SCO MPX are trademarks of The Santa Cruz Operation. UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited. Banyan and VINES are registered trademarks of Banyan Systems, Inc. Hayes is a trademark of Hayes Microcomputer Products Incorporated. pcANYWHERE32 is a trademark of Symantec Corporation. CompuServe is a U.S. registered trademark of CompuServe, Inc.

Hewlett-Packard Company
Network Server Division
Technical Marketing / MS 49EU-FQ
5301 Stevens Creek Boulevard
P.O. Box 58059
Santa Clara, CA 95052-8059, USA

©Copyright 1998, Hewlett-Packard Company

Contents

1 Quick Start.....	1
2 Remote Administration Using the HP Integrated Remote Assistant.....	5
Integrated RA in Action	6
Documentation.....	7
Integrated RA Features and Functions	7
Console Redirection.....	7
Management and Security	8
Server Supervision	8
Other Features.....	9
Integrated RA System Requirements	9
Supported Network Operating Systems.....	10
Remote Client Installation Requirements	11
3 Integrated RA Setup and Configuration	13
Setting Up the Remote Connection	14
Using an External Modem.....	14
Using a Direct Serial Connection.....	15
Using Integrated RA With Terminal Servers.....	17
Configuring Integrated RA.....	19
Checking Server BIOS Communications Parameters.....	19
Setup Using the Integrated RA Configuration Utility	20
Using the Integrated RA Configuration Utility	21
Configuring Communications/Modem	23
Configuring Administrators.....	26
Configuring Server Identification/KeyMap	33
Configuring Event Management.....	34
Display Version Information	36
Exit.....	37
Installing or Updating a Utility Partition.....	38
Using DOS File Transfer on Servers Without a Utility Partition	39
4 Setting Up Console Redirection for Microsoft Windows NT Servers	41
Installing pcANYWHERE32 on the Server	42
Installing pcANYWHERE32	42

5 Setting Up the Remote Client	45
Setting Up Terminal Emulation	45
Option 1: Managing a Server Remotely Using pcANYWHERE32	46
Option 2: Managing a Server Using a Dedicated Terminal	49
6 Using Integrated RA to Manage Server Operations	53
Using Integrated RA's Management Features	53
Integrated RA Management Program Options	54
1. Show Event Log	54
2. Show Status	57
3. Console Redirection	57
4. Server Reset/Power Menu	61
5. Reboot to Utility Partition	63
6. Event Management Configuration	63
7. Administrator/Pager Configuration	64
8. Management Port Passthru	67
0. Disconnect	67
Using SNMP Server Management Applications with Integrated RA	68
7 Troubleshooting	69
Modem	69
Paging	69
Remote Client	71
DOS File Transfer	72
A Event Codes	75
B Recommended Modems	83
C Keyboard Layouts	85
D Keyboard Mapping	89
E Software License, Warranty, and Support	91
HP Software License Agreement	91
Warranty	92
Technical Support	92
Index	93